JVC Everio Digital Camera and Share Station

Video Recording Quick Guide:

1. Slide the mode switch to select Video mode (blue slider on panel side of camera)
2. Select recording mode (button: Play/Rec)
    a. The mode changes when you press the button
3. Start recording (Record button near hand strap where thumb rests)
    a. Press the Start/Stop button to start recording and again to stop.

DVD Creation Quick Guide:

Connect Camera to DVD Share Station

1. Make sure to have a DVD-R, DVD-RW, or DVD-R DL
2. Connect the Share Station to Camera
    a. Plug Share Station into AC adaptor
    b. Connect the USB cable from the Share Station to the front of the Camera
    c. Plug the Camera into AC adaptor
3. Open DVD Share Station tray and insert the disc
4. Close the tray
5. Open LCD monitor of Camera

Copying All Files to DVD

1. Press [DIRECT DV] button, found on inside of touch panel
2. Select [EXECUTE] and press OK (use touch slider to select)
3. The “CREATING NOW” screen appears and copying starts
    a. To cancel select STOP and press OK
4. When “COMPLETED” appears, press OK to complete copying

Copying by Date

1. Display the “CREATE DVD” screen, select “SELECT AND CREATE” and press OK
2. Select “CREATE BY DATE” and press OK
3. Select the desired dates and press OK
4. Select “ALL” and press OK
5. Select “EXECUTE” and press OK
6. The “CREATING NOW” screen appears and copying starts
    a. To cancel select STOP and press OK
7. When “COMPLETED” appears, press OK to complete copying.

PRO TIPS:

1. Use tripod whenever possible
2. Do not pan/tilt excessively

NOTE: The lens is not as fast as the human eye, make sure to pan/tilt slowly

3. Do not zoom in/out excessively
4. Make sure subject is well lit (strong backlighting will cause subject to appear in shadow)
5. Stay within 10 feet of subject to obtain quality audio
    a. Be conscious of surrounding ambient noise (close eyes and actively listen to your surroundings for five seconds)